

(1) at

Parameter Setting Menus

Press SET KEY  to enter the Parameter Setting Menu

Password 17


Users can SET the value for the parameters enabled in the Menu 1 section.

*Installation Note:

It is been advised that the settings should be done by a professional, after going through user operating manual and after having understood the application.

Menu 1 - Password 12

Press  set key for 3 sec. to enter the Configuration Menu



Menu 2 - Password 17

Press  set key for 3 sec. to enter the Configuration Menu

